



Snorkel Patching

MANDATORY Personal Protective Equipment:

- Hard hat.
- Eye protection.
- Shield while filling tar.
- Gloves.
- Safety vest.
- Boots.
- Long sleeves when filling tar.
- First Aid Kit.

RECOMMENDED Personal Protective Equipment:

- Hearing protection.
- Tyvek suit when filling tar.

Sequence of Basic Job Steps:

1. Daily Vehicle Condition Inspection.
2. Fill tank with oil and stone.
3. Spray oil cover with stone.
4. Spray tar and stone mix.
5. Cover any bleed through with stone.

Recommended Safe Job Procedures:

1. Wear PPE listed.
2. Wear seat belt.
3. Check before/after use.
4. Make sure area is clear.
5. Stop and clear from roadway.
6. Stop when traffic is traveling by.
7. Wear PPE when outside and equipment is running.
8. Use vehicle beacon.
9. Use arrow board.
10. Use hazard flashers.
11. If road is closed to through traffic, 911 must be notified.



Potential Accidents and Hazards:

- Traffic.
- Burns.
- Flying debris.
- Debris in roadway.
- Signs (Traffic Control).
- Dust.